

# EXO-TEC Manufacturing, Inc.

626 Main Street, Suite 2.2 Bolton, MA01740 P 508-580-0901

[www.exo-tec.co](http://www.exo-tec.co)

## **Technical Note 01: How to avoid warping of Jam-Ex® during the spray foam installation**

Using best installation practice will substantially reduce if not eliminate warping of the protruding leg of Jam-Ex®. This involves “picture framing” of the interior corner of Jam-Ex®. “Picture framing” is installing a cant or cove at the interior angle of Jam-Ex®. Here is how to do this.

### **Step 1: Install a spray foam cant or cove at the interior corner of Jam-Ex®**



**Step 2: Allow the spray foam cant or cove to cool to within 10° F of the ambient air temperature**



**Step 3: Fill in the area adjacent to the “picture framed” Jam-Ex®**



The thermally set spray foam cant or cove will hold the protruding leg of the Jam-Ex® in its original shape.

